
PEI3070

70 cm INDUCTION WHITE BACKLIGHT FLEXI-ZONE COOKTOP



Features

4 Induction heating elements: Faster heat times (compared to Hi-Lights elements), with a uniform heat distribution. 4 cooking zones with bridges.

Booster: Enables you to cook quicker than usual.

Pan Sensor: Recognises the dimension of the cookware and it determines the size of the cooking zone accordingly.

Timer: 99 minutes multifunctional timer allows you to set the time individually for each heater.

Child Safety Lock: Let you avoid kids for activating the cooking surface simply touching a button.

Automatic Safety Switch off: Automatically turns off any cooking zones if you have forgotten to turn it off or if there is no change in the operation after a certain period.

Residual Heat lights: Allows you to see that the surface of the cooktop is still hot, preventing accidents.

Overflow Protection: Prevents overflowing any liquid form onto the cooktop surface.

9 stage temperature control: With 9 different settings, you can select the ideal cooking temperature for all types of foods to provide the perfect cooking results.

Automatic Pan & Bridge Function: It is a function that automatically detects where the pot or pan is located. Depending on the size of the pot or pan, the bridge function is automatically activated. You just need to power up with the slider.

